

PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES/
AIRCRAFT PARKING/DOCKING CHART

ELEV AD 191 M

TWR	118.7
APP	121.4
VOR/DME	112.8

HERMOSILLO

AEROPUERTO INTL. /
INTL. AIRPORT

GRAL. IGNACIO PESQUEIRA GARCIA

RWY 05/23

**PLATAFORMA DE AVIACION COMERCIAL/
COMMERCIAL AVIATION APRON**

POSICIONES / POSITIONS	RESISTENCIA / STRENGTH	TIPO / TYPE
1	60 R/A/X/T	CONCRETO / CONCRETE
2 - 6	50 R/A/X/T	
7 - 10	60 R/A/X/T	

**PLATAFORMA DE AVIACION COMERCIAL/
COMMERCIAL AVIATION APRON**

TWY "B"

TWY "A"

VAR. MAGNETICA 11° E
MAGNETIC VAR. 11° E

ELEVACIONES Y DIMENSIONES EN METROS
/ELEVATIONS AND DIMENSIONS IN METERS



TWR

TERMINAL

ESCALA / SCALE : 1 : 2000

0 20 40 60 80 M

CAMBIOS/ CHANGES: TEXTO / TEXT

COORDENADAS INS, DE PUESTOS DE ESTACIONAMIENTO DE AERONAVES AVIACION COMERCIAL /
COORDINATES INS, FOR AIRCRAFT STANDS, COMMERCIAL AVIATION

POSICION/ POSITION	LAT (N)	LONG (W)
1	29° 05' 28.2075"	111° 03' 03.3732"
2	29° 05' 27.3413"	111° 03' 05.0081"
3	29° 05' 26.5845"	111° 03' 06.4130"
4	29° 05' 25.8300"	111° 03' 07.8410"
5	29° 05' 25.0759"	111° 03' 09.2537"
6	29° 05' 24.3312"	111° 03' 10.6113"
7	29° 05' 23.5999"	111° 03' 11.9699"
8	29° 05' 22.8901"	111° 03' 13.3256"
9	29° 05' 22.2099"	111° 03' 14.6468"
10	29° 05' 21.5045"	111° 03' 15.9534"