

PLANO DE AERODROMO PARA
MOVIMIENTOS EN TIERRA /
AERODROME GROUND MOVEMENTS CHART
(A380, B747-8 & ANTONOV 124)

RWY 23 L

RUTA DE OPERACION DE AERONAVES CLAVE DE REFERENCIA "F"
PISTA 05R-23L EXCLUSIVA PARA SU OPERACION DE DESPEGUE Y ATERRIZAJE /
OPERATION ROUTE FOR AIRCRAFT CAT "F"
RWY 05R-23L EXCLUSIVE FOR TAKE OFF AND LANDING

MEXICO
AEROPUERTO INTL./
INTL. AIRPORT
BENITO JUAREZ

A380 Y B747-8 EN SALIDA DE POSICIONES 33A Y 35A, SE REALIZARA EL PUSH BACK HACIA EL SUR Y UNA VEZ SOBRE EL RODAJE "B" SERAN REMOLCADAS AL PUNTO DE ENCENDIDO DE MOTORES ANTES DE LA SALIDA DEL SEI

A380 AND B747-8 LEAVING GATES 33A AND 35A SHALL PUSH BACK TO THE SOUTH, ONCE ON "B" BE TOWED TO THE START UP POINT BEFORE SEI EXIT

A380 Y B747-8 EN ENTRADA A POSICION 35A, DEBERAN ESTAR LIBRES POSICIONES 34, 35 Y 36 O 33A UNICAMENTE CON AERONAVES CLAVE DE REFERENCIA "E".
FOR A380 AND B747-8 TO ENTER GATE 35A, GATES 34, 35 AND 36 MUST BE EMPTY OR 33A ONLY FOR AIRCRAFT REFERENCE CODE "E"

B747-8 EN SALIDA DE POSICION 26, SE REALIZARA EL PUSH BACK HACIA EL SUR Y UNA VEZ SOBRE EL RODAJE "B" EFECTUARA EL ENCENDIDO DE MOTORES. B747-8 LEAVING GATE 26 WILL PUSH BACK TO THE SOUTH, ONCE IN "B" WILL PERFORM ENGINE START-UP

A380 EFECTUARA CARRETEO EN RUTA ESTABLECIDA CON MOTORES 2 Y 3 DE MANERA NORMAL, MANTENIENDO MOTORES 1 Y 4 AL RALENTI./
A380 WILL TAXI AS PER ESTABLISHED ROUTE, WITH POWER FROM ENGINES 2 AND 3, DEEPING ENGINES 1 AND 4 AT IDLE.

PARA EL CRUCE DE PISTAS, SE EFECTUARA PREFERENTEMENTE SIN MANTENER ENTRE PISTAS, CON UNA SOLA AUTORIZACION./
FOR RUNWAYS CROSSING, A SOLE CLEARANCE WILL BE ISSUED PREFERABLY TO AVOID HOLDING BETWEEN RUNWAYS.

RUTA ALTERNA POR RODAJES CERRADOS O DESTINO HANGAR COORDINAR CON COMANDANCIA /
AN ALTERNATE ROUTE DUE TO CLOSED TAXIWAYS OR BOUND TO HANGAR, SHALL BE COORDINATED WITH THE AIRPORT AUTHORITY.

CABECERA 23L EN USO / RUNWAY HEAD 23L IN USE:

← LLEGADAS / ARRIVALS → SALIDAS / DEPARTURES

← LLEGADAS UNICAMENTE B747-8 A POS. 26 /
ARRIVALS B747-8 TO GATE 26 ONLY

■ SIN CARRETEO DE AERONAVES CLAVE DE REFERENCIA "F" /
NO TAXIING FOR AIRCRAFT WITH REFERENCE CODE "F"

■ CON CARRETEO DE AERONAVES A380 Y B747-8 EN RODAJE "B", UNICAMENTE TRANSITO DE AERONAVES B767 Y MENORES EN RODAJE "C".
WHILE A380 AND B747-8 TAXIING ON "B", ONLY B767 AND SMALLER AIRCRAFT TO TAXI ON "C"

PUESTOS DE ESTACIONAMIENTO AUTORIZADOS / APPROVED PARKING PLACES

A380 (33A, 35A)
B747-8 (26, 33A, 35A, 41A, 43, 45, 46A)
AN124 (41A, 46A)

ZONA SIN VISIBILIDAD DESDE TWR, PRECAUCION AL TRANSITAR
ZONE OUT OF SIGHT FROM TWR, PROCEED CAUTIOUSLY

ESCALA / SCALE : 1 : 15500

0 200 400 600 800 1000 M

CAMBIO/ CHANGES: TANGO SUR 2